

Sl.No	MKU PART NUMBER	OEM REF PART NUMBER	MODEL	PART DESCRIPTION
<b>Engine: Cummins</b>				
1	8179822	4089911	ISX-15	Water pump
2	8179818	4089909	QSX-15	Water pump
3	7368900	3684450	X15	Water pump
4	7294060	3647030	KTA50	Water pump
5	9911910	4955955	QSX-15	Oil pump
6	7606738	3803369	NT855	Oil pump
7	7607396	3803698	N14	Oil pump
8	7269280	3634640	KTA38	Oil pump
9	8653560	4326780	QSK 60	Injector
10	8752160	4376080	QSK 60	Kit, water pump (3651195)
11	9951266	4975633	QSK 60	Compressor, 2 cyl air
12	10643224	5321612	QSK 60	Kit, turbocharger (4955686)
13	10946802	5473401	QSK 60	Cylinder head rebuild kit
14	7258410	3629205	QSK 60	Thermostat
15	7302758	3651379	QSK 60	Thermostat
16	7282156	3641078	QSK 60	Core, aftercooler (4101030)
17	7283920	3641960	QSK 60	Core, cooler
18	7285778	3642889	QSK 60	Crankshaft
19	7287968	3643984	QSK 60	Con rod bearing
20	7289036	3644518	QSK 60	Pump, lubricating oil
21	7289352	3644676	QSK 60	Rod, con
22	8015482	4007741	QSK 60	Bushing
23	6178346	3089173	QSK 60	Bushing
24	8034578	4017289	QSK 60	Lever, cam follower
25	8049584	4024792	QSK 60	Main bearing (standard)
26	8178286	4089143	QSK 60	Liners with seal
27	9911010	4955505	KT38	Turbocharger
28	7606514	3803257	KT38	Turbocharger repair kit
29	7603606	3801803	KT38	Turbocharger (for above r kit)
30	7287938	3643969	KT38	Water pump (3635783)
31	7269280	3634640	KT38	Oil pump
32	6152978	3076489	KT38	Thermostat
33	7255922	3627961	KT38	Seal, thermostat
34	616104352	3080521BD76	KT38	Fuel pump
35	MK2012	FS1006	KT38	Fuel filter
36	MK1554	LF777	KT38	Oil bypass filter element
37	MK6650	LF3325	KT38	Oil filter (lf3363)
38	MK4146	WF2073	KT38	Water filter
39	410460	205230	KT38	Bushings camshaft
40	6152264	3076132	KT38	Injector
41	6085426	3042713	KT38	Injector cup
42	6835916	3417958	KT38	Air compressor
43	8636428	4318214	KT38	Air compressor
44	6005150	3002575	KT38	Cylinder liner with seals
45	7264450	3632225	KT38	Connecting rod

46	6094780	3047390	KT38	Con rod bearing
47	6087818	3043909	KT38	Con rod bushing
48	7297236	3648618	KT38	Crankshaft
49	6036420	3018210	KT38	Main bearing
50	6098642	3049321	KT38	Camshaft
51	6098644	3049322	KT38	Camshaft
52	6105640	3052820	KT38	Valve in (Inconel)
53	6176778	3088389	KT38	Valve ex, premium, Triballoy
54	6176786	3088393	KT38	Valve in (standard)
55	6176782	3088391	KT38	Valve ex (standard)
56	6052592	3026296	KT38	Insert in, std
57	410186	205093	KT38	Insert ex, std
58	6105638	3052819	KT38	Insert in, premium (Inconel)
59	6404420	3202210	KT38	Valve guide
60	7261256	3630628	KT38	Valve sprint (in & ex)
61	6163602	3081801	KT38	Valve rotator
62	410188	205094	KT38	Spring seat upper
63	6078326	3039163	KT38	Cam follower levers
64	6035922	3017961	KT38	Push rod
65	6114278	3057139	KT38	Push rod
<b>Engine: Detroit Diesel</b>				
1	47065086	23532543	WP07	Water pump
<b>Engine: Volvo</b>				
1	41489878	20744939	D12	Water pump
2	40202386	20101193	D13	Water pump
<b>Engine: International Navistar</b>				
1	364733984	1823669C92	T444E	Water pump
<b>Engine: Ford</b>				
1	MK5000	F5000		Water pump